

= HUS26 (Qty. 21)

= JUS24 (Qty. 7)

▲= Denotes Left End of Truss (Reference Engineered Truss Drawing) Truss Placement Plan SCALE: 1/4" = 1'-0"

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs



TRUSSES & BEAMS Reilly Road Industrial Park

Fayetteville, N.C. 28309 Phone: (910) 864-8787

Fax: (910) 864-4444

earing reactions less than or equal to 3000# are semed to comply with the prescriptive Code quirements. The contractor shall refer to the tached Tables (derived from the prescriptive Code squirements) to determine the minimum foundation ze and number of wood studs required to support sactions greater than 3000# but not greater than 5000#. A registered design professional shall be stained to design the support system for any saction that exceeds those specified in the attache ables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Christine Shivy

Christine Shivy

LOAD CHART FOR JACK STUDS

(8ASÉD ON TABLÉS ROCES(1) & (b)) NUMBER OF JACK STUDS REQUIRED & EA END OF

		-	HEADER/6	STRDER		
END REACTION (UP TO)	REQ'O STUDS FOR (2) PLY HEADER		END REACTION (OF TU)	REQ16 STUDS FOR (3) ALY HEADER	END REACTION (UP TO)	REQUE STUDS FOR (4) PLY HEADER
1700	1		2550	1	3400	1
3400	2		5100	2	6800	2
5100	3		7650	3	10200	3
6800	4		10200	4	13600	4
8500	5		12750	5	17000	5
10200	6		15300	6		
11900	7					
13600	8					
15300	9					

Weaver Development	CITY / CO.	CI TY / CO. Lillington / Harnett	15300
Lot 8 O'Quinn	ADDRESS	Grameta Lane	9
Barstow II "A" 3 Car	MODEL	Roof	
Seal Date	DATE REV. / /	//	
Quote #	DRAWN BY	DRAWN BY Christine Shivy	
J1221-6806	SALES REP.	SALES REP. Lenny Norris	


THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

SEAL DATE

JOB NAME

BUILDER

QUOTE 7



= HUS26 (Qty. 21)

= JUS24 (Qty. 7)

▲= Denotes Left End of Truss (Reference Engineered Truss Drawing) Truss Placement Plan SCALE: 1/4" = 1'-0"

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs

соттесн **ROOF & FLOOR** TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

ring reactions less than or equal to 3000# are med to comply with the prescriptive Code irrements. The contractor shall refer to the ched Tables (derived from the prescriptive Couirements) to determine the minimum foundation and number of wood studs required to supportions greater than 3000# but not greater than te and number or wood studs required to suppor actions greater than 3000# but not greater than 000#. A registered design professional shall be tained to design the support system for any action that exceeds those specified in the attach bles. A registered design professional shall be tained to design the support system for all actions that exceed 15000#.

Christine Shivy

Christine Shivy

LOAD CHART FOR JACK STUDS (BASED ON TABLES ROOZ 5(1) & (b))

Weaver Development	CI TY / CO.	CI TY / CO. Lillington / Harnett	
Lot 8 O'Quinn	ADDRESS	Grameta Lane	
Barstow II "A" 3 Car	MODEL	Roof	
Seal Date	DATE REV. / /	//	
Ouote #	DRAWN BY	DRAWN BY Christine Shivy	
J1221-6806	SALES REP.	SALES REP. Lenny Norris	

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE

QUOTE 7

JOB

BUILDER