THIS LAYOUT IS INTENDED FOR THE PURPOSE OF TRUSS LOCATION AND PLACEMENT ONLY. REFER TO THE BUILDING PLANS FOR ACTUAL BUILDING CONSTRUCTION.



Truss Connector Total List		
Manuf	Product	Qty
Simpson	HUS26	10

1st Level Floor Area	2nd Level Floor Area	
1451.83	1451.83	
1st Level Roof Area	2nd Level Roof Area	Indicates Left End of Truss
3786	0	

84 LUMBER COMPONENTS

DEDICATED TO QUALITY AND EXCELLENCE
200 EMMETT ROAD
DUNN, NORTH CAROLINA 28334
PHONE: 910-892-8400

PROJECT: LAUREN WELLONS JOB - FLOOR
CUSTOMER: WELLONS CALL DUANE
MODEL:
SCALE: N.T.S
DRAWN BY:
QUOTE #: 29653
PRINT DATE: 12/17/2021

GENERAL NOTES:

- IT IS THE RESPONSIBILITY OF THE BUILDER TO PRODVIDE ADEQUATE SUPPORT FOR ALL MEMBERS DISPLAYED ON THIS DRAWING.
- DO NOT CUT OR MODIFY TRUSSES
- BUILDER IS RESPONSIBLE TO VERIFY ALL DIMENSIONS, PLUMBING AND HVAC DROPS / RISE LOCATIONS PRIOR TO TRUSS PLACEMENT.
- REFER TO THE INDIVIDUAL TRUSS DESIGN DRAWINGS FOR THE LOCATION OF LATERAL BRACING AND MULTI-PLY CONNECTION REQUIREMENTS.
- PER ANSI TPI 1-2002 THE TRUSS ENGINEER IS RESPONSIBILE FOR TRUSS TO TRUSS CONNECTIONS AND TRUSS PLY TO PLY CONNECTIONS. THIS TRUSS PLACEMENT PLAN RECOMMENDS TRUSS TO BEARING CONNECTIONS AND TRUSS TO BEAM CONNECTIONS WHICH SHALL BE REVIEWED BY THE BUILDING DESIGNER. IT IS THE RESPONSIBILITY OF THE BUILDING DESIGNER TO RESOLVE ALL ROOF FORCES ADEQUATELY TO THE FOUNDATION.