



Dimension Notes 1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise 2. All interior wall dimensions are to face of stud unless noted otherwise
3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

Red Hatching Indicates 2nd Floor Plate Height

Roof Area = 2667.79 sq.ft. Ridge Line = 43.97 ft. Hip Line = 30.4 ft. Horiz. OH = 238.04 ft. Raked OH = 184.94 ft. Decking = 92 sheets

All Walls Shown Are Considered Load Bearing



Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Hampton Horrocks

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

	(-				 -,,	
NUM	ABER C	F JAC	K STUDS F HEADER/		A END OF	7
(UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
700	1		2550	1	3400	1
400	2		5100	2	6800	2
100	3		7650	3	10200	3
300	4		10200	4	13600	4
500	5		12750	5	17000	5
200	6		15300	6		
900	7					
600	8					
300	9					

Caviness & Cates Communities	COUNTY	Harnett
Lot 201 Anderson Creek	ADDRESS	202 Kensington Dr
CC-2574 C ROOF W / REAR PORCH	MODEL	32000
3/30/2021	DATE REV.	12/16/21 11:27:57
Quote #	DRAWN BY	DRAWN BY Hampton Horrocks
J1221-6754	SALESMAN	SALESMAN Scot Duncan

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

PLAN

SEAL DATE

J1221-6754

QUOTE#

JOB NAME

BUILDER