


\bigcirc	THF25140		USP	32	NA	1()d/3"	10d/3"		
	THF	25140-2	USP	01	NA	1()d/3"	10d/3"		
Products										
Plo	otID	Length	Proc	duct			Plies	Net Qty	Fab Type	÷
Bk	:1	2-0-0	14"	NI-4()x		1	1	FF	
DE	31	7-0-0	1-3/	4"x 9	-1/4" LVL Kerto	-S	2	2	FF	
DE	32	10-0-0	1-3/	4"x 1	1-7/8" LVL Kert	o-S	2	2	FF	
FB	31	12-0-0	1-3/	4"x 1	4" LVL Kerto-S		2	2	FF	
FB	32	24-0-0	1-3/	4"x 2	3-7/8" LVL Kert	o-S	4	4	FF	
FB	33	13-0-0	1-3/	4"x 1	4" LVL Kerto-S		2	2	FF	
FJ1		35-3-6	14"	NI-4(Эх		1	8	FF	
FJ	1A	35-5-4	14"	NI-4(Эх		1	1	FF	
FJ	2	19-10-8	14"	NI-4(Эх		1	1	FF	
FJ	3	19-7-14	14"	NI-4(Эх		1	5	FF	
FJ4		16-0-12	14"	NI-4(Эх		1	1	FF	
FJ	5	15-11-13	14"	NI-4(Эх		1	6	FF	
FJ	6	15-9-9	14"	NI-4(Эх		1	5	FF	
FJ	7	15-9-3	14"	NI-4(Эх		1	6	FF	
FJ	8	4-1-2	14"	NI-4(Эх		1	1	FF	
FJ	9	3-9-9	14"	NI-4(Эх		1	1	FF	
G	ЭН	24-0-0	2x12	2 SP	No.2		3	3	FF	
RI	M1	12-0-0	1 1/3	8" x ´	14" Rim Board		1	11	FF	



<u>Truss</u> <u>Placement</u> <u>Plan</u> SCALE: 1/4"=1' = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards