



Dimension Notes 1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise

2. All interior wall dimensions are to face of frame wall unless noted otherwise

3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

	Conne	ctor Info	rmat	ion	Nail Info	ormation
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	15	Varies	16d/3-1/2"	16d/3-1/2"

		Products			
PlotID	Length	Product	Plies	Net Qty	Fab Type
GDH	21' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF
BM1	14' 0"	1-3/4"x 16" LVL Kerto-S	2	2	FF
BM2	22' 0"	1-3/4"x 23-7/8" LVL Kerto-S	2	2	FF

соттесн **ROOF & FLOOR TRUSSES & BEAMS**

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Anthony Williams

LOAD CHART FOR JACK STUDS

LO	AD (-MAI	KIFU	KJ	ACK.	5100	3
	(B	ASED C	N TABLES	5 R502	.5(1) & (l	o))	
NUA	MBER C		STUDS R			A END OF	-
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END RE <i>AC</i> TION (UP TO)	REQ'D STUDS FOR
1700	1		2550	1		3400	1
3400	2		5100	2		6800	2
5100	3		7650	3		10200	3
6800	4		10200	4		13600	4
8500	5		12750	5		17000	5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

COUNTY	Harnett County
ADDRESS	Lot 8 Williams Farm / Erwin, NC
MODEL	Floor
DATE REV.	5/29/23
DRAWN BY	DRAWN BY Anthony Williams
SALESMAN	SALESMAN Anthony Williams

Clark 1960 / 170328B Lot 8 Williams Farms J0523-2746 2/16/15 Z Z JOB NAME SEAL DATE QUOTE# THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

Signature Home Builders

BUILDER

Truss Placement Plan SCALE: 1/4" = 1'