

HUS410	USP	4	NA	16d/3-1/2"	16d/3-1/2"
THD410	USP	4	NA	16d/3-1/2"	10d/3"
MSH422	USP	10	Varies	10d/3"	10d/3"

		Products			
PlotID	Length	Product	Plies	Net Qty	Fab Type
FB3	8-0-0	1.75 X 14 Kerto-S LVL 2.0E	2	2	FF
FB2	6-0-0	1.75 X 14 Kerto-S LVL 2.0E	2	4	FF
TFB1	20-0-0	1.75 X 24 Kerto-S LVL 2.0E	3	3	FF
DB1	5-0-0	1-3/4"x 9-1/4" LVL Kerto-S	2	2	FF
Front GDH	20-0-0	1-3/4"x 14" LVL Kerto-S	3	3	FF

= Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards

соттесн
ROOF & FLOOR
TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

ture Marshall Naylor

Marshall Naylor

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R502.5(1) & (b))

		 			. , ,	
NU/	MBER C	STUDS F HEADER/			A END C	Þ
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END REACTION (UP TO)	
1700	1	2550	1		3400)
3400	2	5100	2		6800)
5100	3	7650	3		10200)
6800	4	10200	4		13600	כ
8500	5	12750	5		17000)
10200	6	15300	6			
11900	7					
13600	8					
15300	9					
	1			1		

CITY / CO.	CITY / CO. Cameron / Cumberland
ADDRESS	Wolcott Court
MODEL	Floor Trusses
DATE REV.	06/24/22
DRAWN BY	DRAWN BY Marshall Naylor
SALES REP.	Marshall Naylor

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

8/3/2021

A & G Residential