


## All Walls Shown Are Considered Load Bearing


Roof Area = 2147.16 sq.ft. Ridge Line = 71.84 ft. Hip Line = 0 ft. Horiz. OH = 110.23 ft. Raked OH = 151.18 ft. Decking = 74 sheets

Dimension Notes 1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise 2. All interior wall dimensions are to face of frame wall unless noted otherwise 3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise



	Connector Information					Nail Information	
Sym	Product	Manuf	Qty	Supported Member	Header	Truss	
	HUS26	USP	5	NA	16d/3-1/2"	16d/3-1/2"	

		Products		
PlotID	Length	Product	Plies	Net Qty
GDH	22' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2





Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

earing reactions less than or equal to 3000# are seemed to comply with the prescriptive Code equirements. The contractor shall refer to the tached Tables ( derived from the prescriptive Code equirements) to determine the minimum foundatic ze and number of wood studs required to supportactions greater than 3000# but not greater than 5000#. A registered design professional shall be stained to design the support system for any faction that exceeds those specified in the attached ables. A registered design professional shall be stained to design the support system for all factions that exceed 15000#.

David Landry

David Landry

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER END REACTION
(UP TO)
REQ'D STUDS FOF
(4) PLY HEADER 3400 1 1700 1 2550 1 3400 2 6800 2 5100 2 5100 3 7650 3 10200 3 6800 4 10200 4 13600 4 8500 5 12750 5 17000 5 10200 6 15300 6

11900 7 13600 8 15300 9 Johnston Co. / Johnston Jonathan Landry Lenny Norris 07/13/22 DRAWN BY SALES REP. CI TY / CO.

J0722-3619 Plan N/A JOB NAME SEAL DATE QUOTE 7 THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

Wellco Contractors

**BUILDER**