



соттесн

ROOF & FLOOR

TRUSSES & BEAMS

ng reactions less than or equal to 3000# are and to comply with the prescriptive Code ze and number or wood studs required to suppor actions greater than 3000# but not greater than 5000#. A registered design professional shall be stained to design the support system for any saction that exceeds those specified in the attach ables. A registered design professional shall be stained to design the support system for all sactions that exceed 15000#.

David Landry

David Landry

LOAD CHART FOR JACK STUDS

(8ASÉD ON TABLÉS ROCES(1) & (b)) NUMBER OF JACK STUDS REQUIRED & EA END OF

1401	MEER C	HEADER/		in cine o	"
END REACHON (0P 10)	REQ'D STUDS FOR (2) PLY HEADER	ENS REACTION (OF TD)	REQ15 STUDS FOR (3) MW HEADER	END REACTION (UP TO)	REQUESTUDS FOR
1700	1	2550	1	3400	1
3400	2	5100	2	6800	2
5100	3	7650	3	10200	
6800	4	10200	4	13600	
8500	5	12750	5	17000) 5
0200	6	15300	6		
1900	7				
3600	8				
5300	9				

David Landry

DRAWN BY SALES REP.

Quote

07/18/22

Lenny Norris

Spring Lake / Harnett

CI TY / CO.

Lot

111 Hidden Lakes

Lot

NAME

JOB

Wellco Contractors

Flush Beam	
Drop Beam	

Dimension Notes 1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of frame wall unless noted otherwise
3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise


Hatch Legend

All Walls Shown Are Considered Load Bearing

Plumbing Drop Notes Plumbing drop locations shown are NOT exact. 2. Contractor to verify ALL plumbing drop locations prior to setting Roof Trusses. 3. Adjust spacing as needed not to exceed 24"oc.

	Connector Information				Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss	
	HUS26	USP	49	NA	16d/3-1/2"	16d/3-1/2"	
	THD26-2	USP	1	NA	16d/3-1/2"	10d/3"	

		Products		
PlotID	Length	Product	Plies	Net Qty
BM1	13' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2
BM2	13' 0"	1-3/4"x 14" LVL Kerto-S	3	3
GDH	24' 0"	1-3/4"x 14" LVL Kerto-S	2	2



= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards

BUILDER QUOTE ; THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE