Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signature *Curtis Quick*

Curtis Quick

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R602.7(1) & (2))
NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
1700	1	2550	1	3400	1
3400	2	5100	2	6800	2
5100	3	7650	3	10200	3
6800	4	10200	4	13600	4
8500	5	12750	5	17000	5
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

Lite Attic Storage
30 lbs. Live Load

Beam Legend labels: BM2, BM1, BM3, D1GE, D1, D2, D3, VD1, VD2, VD3, C2GE, C2, B1, B1GE, C1, C1GE, A3GE, A3, A2, A1, A1GE, PB1GE, PB1, VA1, VA2, VA3, VA4, VA5, VA6

61' 7"
23' 8"
34' 2"
3' 9"
24' 4"
61' 8"
29' 4"
34' 3 1/2"
8' 0"
12' 0"
33' 10"
15' 9"
7' 4 1/2"
12' 0"

CITY / CO.	Harnett Co. / Harnett
ADDRESS	Site Address
MODEL	Model
DATE REV.	08/19/22
DRAWN BY	Curtis Quick
SALES REP.	Lenny Norris

BUILDER	Jamie Fisher
JOB NAME	Fisher Residence
PLAN	Honeysuckle
SEAL DATE	Seal Date
QUOTE #	Quote Date
JOB #	J0822-4240

▲ = Denotes Left End of Truss
(Reference Engineered Truss Drawing)
Do Not Erect Trusses Backwards

Truss Placement Plan
SCALE: 3/16" = 1'

Beam Legend

PlotID	Length	Product	Plies	Net Qty	Fab Type
BM1	25' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF
BM2	24' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF
BM3	20' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com