

Estimation						
Name	Selection	Formula	Calculation			
Roof Area	1st Floor	Roof Area	2863.59			
Roof Decking	1st Floor	Roof Decking	98			

Products					
PlotID	Length	Product	Plies	Net Qty	Fab Type
GDH (dropped)	23-00-00	1-3/4"x 14" LVL Kerto-S	2	2	FF

Truss Placement Plan SCALE: 1/4" = 1'0"

▲= Denotes Left End of Truss (Reference Engineered Truss Drawing)

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs.

Reaction / # of Studs

deemerequire attache Code refoundarequire but not profess suppor those seregiste design	d to compenents. The d Tables equirement of the titon size ed to supper the transfer of the tr	ply with the contra (derived nts) to d and numl port react than 1500 all be reta for any re in the atta in profess	ne prescretor shall from the etermine ber of wo ions grea 0#. A regined to deaction that is the control of the	ter than 3 istered de esign the nat exceed	de the tive num 8000# esign ds	
\$	Signature _.	Lenr	ıy No	rris	_	
	(BASED	ON TABLE	S R502.5(1			
	700 1 2550 1 3400 1 400 2 5100 2 6800 2 100 3 7650 3 10200 3 800 4 10200 4 13600 4 500 5 12750 5 17000 5 1200 6 15300 6					
Harnett	Wendywood Dr.	Model	//	DRAWN BY Lenny Norris	SALESMAN Lenny Norris	
COUNTY	ADDRESS	MODEL	DATE REV. / /	DRAWN BY	SALESMAN	
Southern Touch Homes	Lot 22 West Preserve	Sinclair (190320B) 3Car	Seal Date	Quote #	J0523-2757	
BUILDER	JOB NAME	PLAN	SEAL DATE	флоте #	JOB #	
THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com						


COMTECH

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787

Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are



Estimation						
Name	Selection	Formula	Calculation			
Roof Area	1st Floor	Roof Area	2863.59			
Roof Decking	1st Floor	Roof Decking	98			

Products						
PlotID	Length	Product	Plies	Net Qty	Fab Type	
GDH (dropped)	23' 0"	1-3/4"x 14" LVL Kerto-S	2	2	FF	

Truss Placement Plan SCALE: 1/4" = 1'0"

▲= Denotes Left End of Truss (Reference Engineered Truss Drawing)

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs.

Reaction / # of Studs

Noted Otherwise. ter than 3,000 lbs. # of Studs	These to compose design See indidentific design perman for the support and coldesign consult	THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com				
f Truss uss Drawing) us are Less	BUILDER	JOB NAME	PLAN	SEAL DATE	QUOTE #	JOB #
	Southern Touch Homes	Lot 22 West Preserve	Sinclair (190320B) 3Car	Seal Date	Quote #	J0523-2757
	COUNTY	ADDRESS	MODEL	DATE REV.	DRAWN BY	SALESMAN
	Harnett	Wendywood Dr	Model	//	Lenny Norris	Lenny Norris

COMTECH

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Lenny Norris

3400 1

6800 2

10200 3

13600 4

17000 5

LOAD CHART FOR JACK STUDS
(BASED ON TABLES R502.5(1) & (b))

NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

2550 1

5100 2

7650 3

10200 4

12750 5

15300 6

1700 1

3400 2

5100 3

6800 4

8500 5

10200 6

11900 7 13600 8

15300 9

۲