Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signature _Bob Lewis_
Bob Lewis

LOAD CHART FOR JACK STUDS
(BASED ON TABLES R502.5(1) & (b))
NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
1700	1	2550	1	3400	1
3400	2	5100	2	6800	2
5100	3	7650	3	10200	3
6800	4	10200	4	13600	4
8500	5	12750	5	17000	5
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

CITY / CO.	SANFORD / LEE
ADDRESS	LONGLEAF COURT
MODEL	ROOF - 2 STORY
DATE REV.	05/15/23
DRAWN BY	Bob Lewis
SALES REP.	Bob Lewis

BUILDER	GREAT SOUTH BLDRS
JOB NAME	LOT 36L
PLAN	2L-2937
SEAL DATE	Seal Date
QUOTE #	Quote #
JOB #	J0423-1835

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

NI40 JOISTS / RIMBOARD BY COMTECH

PlotID	Length	Product	Plies	Net Qty	Fab Type
1FJ1	32-00-00	11 7/8" NI-40x	1	22	MFD
1FJ2	28-00-00	11 7/8" NI-40x	1	6	MFD
1FJ3	22-00-00	11 7/8" NI-40x	1	7	MFD
1FJ3	22-00-00	11 7/8" NI-40x	2	2	MFD
RIM1	12-00-00	1 1/8" x 11 7/8" Rim Board	1	17	FF

LVL BY COMTECH

PlotID	Length	Product	Plies	Net Qty	Fab Type
1DB1	42-00-00	1-3/4"x 9-1/4" LVL Kerto-S	2	2	FF
BK1	2-00-00	1-3/4"x 11-7/8" LVL Kerto-S	2	4	FF
BK2	1-00-00	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF

Truss Placement Plan
SCALE: NTS

△ = Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards