

	l	CO	DF 8	Te		
	TRUSSES & BEAMS Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444					
	Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.					
	Signature David Landry David Landry					
	LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF					
		BER OF JA BER OF JA 1 2 3 4 5 6 7 8 9	2550 5100 10200 12750	/GIRDER BB BB	e EA END NO LUVE 201 340 680 1020 1360 1700	00 00 00 00 8 0 1 REQ'D STUDS FOR 4 (4) PLY HEADER
	CITY / CO . Sanford / Harnett	83 Oleander Lane	Roof	EV . 01/09/24	DRAWN BY David Landry	SALES REP. Lenny Norris
	CITY /	ADDRESS	MODEL	DATE REV.	DRAWN	SALES
	Weaver Development, Inc.	Lot 29 West Preserve	Lexington	Seal Date	Quote #	J0124-0159
	BUILDER	JOB NAME	PLAN	SEAL DATE	QUOTE #	JOB #
; ving) s	THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com					

▲ = Indicates Left End of Truss (Reference Engineered Truss Drawi Do NOT Erect Truss Backwards