

Plumbing Drop Notes


1. Plumbing drop locations shown are NOT exact. 2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.

3. Adjust spacing as needed not to exceed 24"oc.

> Dimension Notes All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
> All interior wall dimensions are to face of stud unless noted otherwise 3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

All Walls Shown Are Considered Load Bearing

▲ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards



	Conne	ctor Info	rmati	ion	Nail Info	rmation
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	44	NA	16d/3-1/2"	16d/3-1/2"

		Products		
PlotID	Length	Product	Plies	Net Qty
FB1	8' 0"	1-3/4"x 14" LVL Kerto-S	2	2
FB2	6' 0"	1-3/4"x 14" LVL Kerto-S	2	2
FB3	22' 0"	1-3/4"x 18" LVL Kerto-S	3	3
FB4	17' 0"	1-3/4"x 23-7/8" LVL Kerto-S	2	2

COMTECH **ROOF & FLOOR TRUSSES & BEAMS**

> Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

ng reactions less than or equal to 3000# are do to comply with the prescriptive Code ements. The contractor shall refer to the ed Tables (derived from the prescriptive Codements) to determine the minimum foundation of the prescriptive to support the prescriptive to support the prescriptive to support the prescriptive that the pr

Signature Johnnie Baggett

Johnnie Baggett

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R502.5(1) & (b))

		STUDS REQUIRED @ EA END OF HEADER/GIRDER					
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
1700	1		2550	1		3400	1
3400	2		5100	2		6800	2
5100	3		7650	3		10200	3
6800	4		10200	4		13600	4
8500	5		12750	5		17000	5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

CITY / CO.	CITY / CO. Lillington / Harnett
ADDRESS	1701 Neills Creek Road
MODEL	Floor
DATE REV.	11/11/23
DRAWN BY	Johnnie Baggett
SALES REP.	Johnnie Baggett

Creek at Neill's New Home Inc. The Holly -Quote# JOB NAME BUILDER

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. (Reference Engineered Truss Drawing)

= Indicates Left End of Truss

Do NOT Erect Truss Backwards