


= 2221.03 sq.ft. Roof Area = 32.22 ft. Ridge Line Hip Line = 0 ft. = 183.83 ft. Horiz. OH Raked OH = 168.3 ft. = 76 sheets Decking

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss 🛕 (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

WALL SCHE	DULE
1st Floor Walls	
2nd Floor Walls	
Non-Bearing Walls	
Garage Walls Dropped	

Nail Info	ormation	Co	nnec	tor Infor	mation	
Truss	Header	Supported Member	Qty	Manuf	Product	Sym
16d/3-1/2"	16d/3-1/2"	NA	13	USP	HUS26	
10d/3"	10d/3"	NA	12	USP	JUS26	
10d/3"	16d/3-1/2"	NA	1	USP	THD26-2	



соттесн **ROOF & FLOOR TRUSSES & BEAMS**

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

ring reactions less than or equal to 3000# are med to comply with the prescriptive Code uirements. The contractor shall refer to the ached Tables (derived from the prescriptive Code uirements) to determine the minimum foundation is and number of wood studs required to support actions greater than 3000# but not greater than 300#. A registered design professional shall be tained to design the support system for any action that exceeds those specified in the attache ables. A registered design professional shall be stained to design the support system for all eactions that exceed 15000#.

Signature Johnnie Baggett

Johnnie Baggett

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

NUM	MBER C	STUDS F HEADER/		A END O	F
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	PEO'N CTITING EOD
1700	1	2550	1	3400	
3400	2	5100	2	6800	
5100	3	7650	3	10200	
6800	4	10200	4	13600	
8500	5	12750	5	17000	
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

CITY / CO.	CITY / CO. Fuquay Varina / Wake
ADDRESS	302 Yates Mill Drive
WODEL	Roof
DATE REV.	3/5/24
DRAWN BY	DRAWN BY Johnnie Baggett
SALES REP.	SALES REP. Paul Hawkins

New Home Inc The Holly. Quote# 7/1/21 JOB NAME SEAL DATE BUILDER QUOTE;

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com (Reference Engineered Truss Drawing)

Do NOT Erect Truss Backwards