


Dimension Notes All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
 All interior wall dimensions are to face of stud unless noted otherwise
3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

Roof Area = 2195.32 sq.ft. Ridge Line = 62.56 ft. Hip Line = 0 ft. Horiz. OH = 172.67 ft. Raked OH = 153.73 ft. Decking = 75 sheets

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards



	Conne	ctor Info	rmat	on	Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss	
	HUS26	USP	8	NA	16d/3-1/2"	16d/3-1/2"	
	JUS26	USP	10	NA	10d/3"	10d/3"	

COMTECH **ROOF & FLOOR TRUSSES & BEAMS**

> Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

earing reactions less than or equal to 3000# are seemed to comply with the prescriptive Code equirements. The contractor shall refer to the tached Tables (derived from the prescriptive Code quirements) to determine the minimum foundation ze and number of wood studs required to support actions greater than 3000# but not greater than 5000#. A registered design professional shall be tained to design the support system for any action that exceeds those specified in the attached ables. A registered design professional shall be tained to design the support system for all lactions that exceed 15000#.

Signature Johnnie Baggett

Johnnie Baggett

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

Z _O	ig Ki		α		_
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	DEO'N STILLS FOR
1700	1	2550	1	3400	
3400	2	5100	2	6800	
5100	3	7650	3	10200	
6800	4	10200	4	13600	
8500	5	12750	5	17000	
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

CITY / CO.	CITY / CO. Lillington / Harnett
ADDRESS	XXX Duncans Creek Road
MODEL	Roof
DATE REV.	1/2/24
DRAWN BY	Johnnie Baggett
CALECDED	CALES DED Dan Hambins

English Country New Home Inc The Holly Quote# JOB NAME BUILDER

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.con (Reference Engineered Truss Drawing)

= Indicates Left End of Truss

Do NOT Erect Truss Backwards