

# Mark Morris, P.E.

#126, 1317-M, Summerville, SC 29483

843 209-5784, Fax (866)-213-4614

The truss drawing(s) listed below have been prepared by **Atlantic Building Components** under my direct supervision based on the parameters provided by the truss designers.

AST #: 43947

JOB: 23-B565-F01

JOB NAME: LOT 0.0004 HONEYCUTT HILLS

Wind Code: N/A

Wind Speed: Vult= N/A

Exposure Category: N/A

Mean Roof Height (feet): N/A

These truss designs comply with IRC 2015 as well as IRC 2018.

*15 Truss Design(s)*

Trusses:

F101, F102, F103, F104, F105, F106, F107, F107A, F108, F109, F110, F111, F112, F113, F114



**1/4/2024**

**Mark Morris**

***Warning !—Verify design parameters and read notes before use.***

This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 Guide to *Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI




Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F102	Floor	11	1	
					# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:21 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?zynRG-flF4FkzCn?3rwiocZ6aj6jNM9rA8PT23ldXyVnazxyO



Scale = 1:40.9



LOADING (psf)	SPACING-	CSi.	DEFL.	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.33	in (loc) l/defl L/d	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.55	Vert(LL) -0.08 16-17 >999 480		
BCLL 0.0	Lumber DOL 1.00	WB 0.38	Vert(CT) -0.11 16-17 >999 360		
BCDL 5.0	Rep Stress Incr YES	Matrix-SH	Horz(CT) 0.02 14 n/a n/a		
	Code IRC2021/TPI2014			Weight: 124 lb	FT = 20%F, 11%E

**LUMBER-**  
 TOP CHORD 2x4 SP No.1(flat)  
 BOT CHORD 2x4 SP No.1(flat)  
 WEBS 2x4 SP No.3(flat)

**BRACING-**  
 TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
 BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing, Except: 6-0-0 oc bracing: 23-24,22-23,21-22,19-21.

**REACTIONS.** (lb/size) 29=412/0-4-8 (min. 0-1-8), 14=492/0-7-14 (min. 0-1-8), 22=1246/0-4-8 (min. 0-1-8)  
 Max Grav 29=451(LC 3), 14=517(LC 7), 22=1246(LC 1)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-29=-449/0, 14-30=-511/0, 13-30=-510/0, 1-2=-257/0, 2-3=-921/0, 3-4=-1085/0, 4-5=-754/165, 5-6=0/617, 6-7=0/617, 7-8=0/1045, 8-9=-262/245, 9-10=-1121/0, 10-11=-1455/0, 11-12=-1306/0, 12-13=-624/0  
 BOT CHORD 27-28=0/718, 26-27=0/1085, 25-26=0/1085, 24-25=0/1085, 23-24=-327/447, 22-23=-1045/0, 21-22=-689/0, 20-21=-73/812, 19-20=-73/812, 18-19=0/1455, 17-18=0/1455, 16-17=0/1455, 15-16=0/1117  
 WEBS 7-22=-612/0, 2-27=-5/265, 2-28=-599/0, 1-28=0/472, 4-24=-547/0, 5-24=0/478, 5-23=-756/0, 7-23=0/691, 10-19=-527/0, 9-19=0/460, 9-21=-760/0, 8-21=0/791, 8-22=-733/0, 12-15=-642/0, 13-15=0/730

- NOTES-** (4-7)
- 1) Unbalanced floor live loads have been considered for this design.
  - 2) Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - 3) CAUTION, Do not erect truss backwards.
  - 4) Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - 5) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - 6) Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - 7) SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F104	Floor Supported Gable	1	1	
					<b># 43947</b>

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:25 2024 Page 1  
ID:YrqHYj0sGK239HELXZ6g?zynRG-Y3Ub460iqDZGPK6LLPo2tDXv5ndnPXRuY9wjwMzxiyK

0-1-8

Scale = 1:38.3




Plate Offsets (X,Y)-- [11:0-1-8,Edge], [32:0-1-8,Edge], [40:Edge,0-1-8]

LOADING (psf)	SPACING-	2-0-0	CSI.	DEFL.	in (loc)	l/defl	L/d	PLATES	GRIP
TCLL 40.0	Plate Grip DOL	1.00	TC 0.06	Vert(LL)	n/a	-	n/a	MT20	244/190
TCDL 10.0	Lumber DOL	1.00	BC 0.01	Vert(CT)	n/a	-	n/a		
BCLL 0.0	Rep Stress Incr	YES	WB 0.03	Horz(CT)	0.00	21	n/a		
BCDL 5.0	Code IRC2021/TPI2014		Matrix-SH						
								Weight: 99 lb	FT = 20%F, 11%E

**LUMBER-**  
TOP CHORD 2x4 SP No.1(flat)  
BOT CHORD 2x4 SP No.1(flat)  
WEBS 2x4 SP No.3(flat)  
OTHERS 2x4 SP No.3(flat)


**BRACING-**  
TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** All bearings 23-2-10.  
(lb) - Max Uplift All uplift 100 lb or less at joint(s) 21  
Max Grav All reactions 250 lb or less at joint(s) 40, 21, 39, 38, 37, 36, 35, 34, 33, 32, 31, 30, 28, 27, 26, 25, 24, 23, 22

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.

- NOTES-** (7-10)
- Gable requires continuous bottom chord bearing.
  - Truss to be fully sheathed from one face or securely braced against lateral movement (i.e. diagonal web).
  - Gable studs spaced at 1-4-0 oc.
  - Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 100 lb uplift at joint(s) 21.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION, Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard




1/4/2024


**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F105	FLOOR	9	1	# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:26 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?znRG-0F2zIS1KbXi70ThXv7JHQQ3r4Bn78BU1mpgGSozixyJ



Scale = 1:19.5



LOADING (psf)	SPACING-	CSI.	DEFL.	PLATES	GRIP
TCLL 40.0	Plate Grip DOL 1.00	TC 1.00	Vert(LL) -0.04 12 >999 480	MT20	244/190
TCDL 10.0	Lumber DOL 1.00	BC 0.83	Vert(CT) -0.24 12-13 >583 360		
BCLL 0.0	Rep Stress Incr NO	WB 0.88	Horz(CT) 0.03 8 n/a n/a		
BCDL 5.0	Code IRC2021/TPI2014	Matrix-SH		Weight: 71 lb	FT = 20%F, 11%E

**LUMBER-**  
 TOP CHORD 2x4 SP No.1(flat)  
 BOT CHORD 2x4 SP SS(flat)  
 WEBS 2x4 SP No.3(flat)

**BRACING-**  
 TOP CHORD Structural wood sheathing directly applied, except end verticals.  
 BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 17=1195/0-4-8 (min. 0-1-8), 8=921/0-4-8 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-17=-1185/0, 1-2=-1466/0, 2-3=-3986/0, 3-4=-4800/0, 4-5=-3578/0, 5-6=-1966/0  
 BOT CHORD 15-16=0/2800, 14-15=0/2781, 13-14=0/4800, 12-13=0/3578, 11-12=0/3578, 10-11=0/3578, 9-10=0/963, 8-9=0/970  
 WEBS 3-13=-251/0, 4-12=-1038/0, 5-11=0/982, 1-16=0/1840, 2-16=-1736/0, 2-14=0/1506, 3-14=-1447/0, 4-13=0/1700, 5-10=-2012/0, 6-10=0/1264, 6-8=-1301/0

**NOTES-** (5-8)  
 1) Unbalanced floor live loads have been considered for this design.  
 2) Load case(s) 1, 2, 3, 4, 5, 6 has/have been modified. Building designer must review loads to verify that they are correct for the intended use of this truss.  
 3) Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.  
 4) CAUTION. Do not erect truss backwards.  
 5) Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.  
 6) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.  
 7) Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.  
 8) SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard  
 1) Dead + Floor Live (balanced): Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 8-17=-7, 1-7=-67  
 Concentrated Loads (lb)  
 Vert: 3=-1267  
 2) Dead: Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 8-17=-7, 1-7=-67  
 Concentrated Loads (lb)  
 Vert: 3=-1267



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F105	FLOOR	9	1	Job Reference (optional) # 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:26 2024 Page 2  
ID:YrqHYj0sGK239HELXZ6g?zynRG-0F2zIS1KbXi70ThXv7JHQQ3r4Bn78BU1mpgGSozxiyJ


**LOAD CASE(S)** Standard

- 3) 1st chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-7, 1-5=-67, 5-7=-13
  - Concentrated Loads (lb)
    - Vert: 3=-1267
- 4) 2nd chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-7, 1-4=-13, 4-7=-67
  - Concentrated Loads (lb)
    - Vert: 3=-1267
- 5) 3rd chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-7, 1-5=-67, 5-7=-13
  - Concentrated Loads (lb)
    - Vert: 3=-1267
- 6) 4th chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-7, 1-4=-13, 4-7=-67
  - Concentrated Loads (lb)
    - Vert: 3=-1267



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 Guide to *Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



Scale = 1:19.2




Plate Offsets (X,Y)-- [3:0-1-8,Edge], [4:0-1-8,Edge], [14:Edge,0-1-8]					
<b>LOADING</b> (psf)	<b>SPACING-</b> 1-7-3	<b>CSI.</b>	<b>DEFL.</b> in (loc) l/defl L/d	<b>PLATES</b>	<b>GRIP</b>
TCLL 40.0	Plate Grip DOL 1.00	TC 0.21	Vert(LL) -0.06 9-10 >999 480	MT20	244/190
TCDL 10.0	Lumber DOL 1.00	BC 0.41	Vert(CT) -0.08 10 >999 360		
BCLL 0.0	Rep Stress Incr YES	WB 0.28	Horz(CT) 0.02 7 n/a n/a		
BCDL 5.0	Code IRC2021/TPI2014	Matrix-SH			
				Weight: 61 lb	FT = 20%F, 11%E

**LUMBER-**  
TOP CHORD 2x4 SP No.1(flat)  
BOT CHORD 2x4 SP No.1(flat)  
WEBS 2x4 SP No.3(flat)

**BRACING-**  
TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 14=509/0-4-8 (min. 0-1-8), 7=509/0-4-8 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
TOP CHORD 1-14=-508/0, 6-7=-508/0, 1-2=-389/0, 2-3=-1151/0, 3-4=-1396/0, 4-5=-1151/0, 5-6=-389/0  
BOT CHORD 12-13=0/899, 11-12=0/1396, 10-11=0/1396, 9-10=0/1396, 8-9=0/899  
WEBS 3-12=-385/0, 2-12=0/329, 2-13=-664/0, 1-13=0/589, 4-9=-385/0, 5-9=0/329, 5-8=-664/0, 6-8=0/589

- NOTES-** (3-6)
- Unbalanced floor live loads have been considered for this design.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET - PERMANENT RESTRAING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.


**LOAD CASE(S)** Standard




1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.





Scale = 1:19.8



LOADING (psf)	SPACING-	CSI.	DEFL.	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.25	in (loc) l/defl L/d	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.45	Vert(LL) -0.07 9-10 >999 480		
BCLL 0.0	Lumber DOL 1.00	WB 0.31	Vert(CT) -0.09 9-10 >999 360		
BCDL 5.0	Rep Stress Incr YES	Matrix-SH	Horz(CT) 0.02 7 n/a n/a		
	Code IRC2021/TPI2014			Weight: 62 lb	FT = 20%F, 11%E

**LUMBER-**  
 TOP CHORD 2x4 SP No.1(flat)  
 BOT CHORD 2x4 SP No.1(flat)  
 WEBS 2x4 SP No.3(flat)

**BRACING-**  
 TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
 BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 14=523/0-4-8 (min. 0-1-8), 7=518/0-7-14 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-14=-522/0, 7-15=-514/0, 6-15=-514/0, 1-2=-400/0, 2-3=-1195/0, 3-4=-1469/0, 4-5=-1257/0, 5-6=-518/0  
 BOT CHORD 12-13=0/925, 11-12=0/1469, 10-11=0/1469, 9-10=0/1469, 8-9=0/1025  
 WEBS 3-12=-417/0, 2-12=0/352, 2-13=-682/0, 1-13=0/606, 4-9=-364/0, 5-9=0/314, 5-8=-661/0, 6-8=0/655

- NOTES-** (4-7)
- Unbalanced floor live loads have been considered for this design.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION. Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard




1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F107A	FLOOR	4	1	# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:28 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?zynRG-yeAjj72b78yrGnqv0YLIVr9F\_?Vhc68KE69NXhziyH



Scale = 1:20.2




Plate Offsets (X,Y)-- [1:Edge,0-1-8], [4:0-1-8,Edge], [5:0-1-8,Edge], [11:0-3-0,0-0-0], [17:Edge,0-1-8]

LOADING (psf)	SPACING-	CSI.	DEFL.	in (loc)	l/defl	L/d	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.72	Vert(LL)	-0.05	12	>999	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.70	Vert(CT)	-0.21	12-13	>679		
BCLL 0.0	Lumber DOL 1.00	WB 0.80	Horz(CT)	0.03	8	n/a		
BCDL 5.0	Rep Stress Incr NO	Matrix-SH						
	Code IRC2021/TPI2014						Weight: 72 lb	FT = 20%F, 11%E

LUMBER-	BRACING-
TOP CHORD 2x4 SP No.1(flat)	TOP CHORD Structural wood sheathing directly applied or 5-10-10 oc purlins, except end verticals.
BOT CHORD 2x4 SP SS(flat)	BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.
WEBS 2x4 SP No.3(flat)	

REACTIONS. (lb/size) 17=1116/0-4-8 (min. 0-1-8), 8=884/0-7-14 (min. 0-1-8)

FORCES. (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-17=-1105/0, 1-2=-1343/0, 2-3=-3576/0, 3-4=-4267/0, 4-5=-3393/0, 5-6=-2039/0  
 BOT CHORD 15-16=0/2562, 14-15=0/2544, 13-14=0/4267, 12-13=0/3393, 11-12=0/3393, 10-11=0/3393, 9-10=0/1156, 8-9=0/1164  
 WEBS 4-12=-836/0, 5-11=0/801, 1-16=0/1685, 2-16=-1586/0, 2-14=0/1288, 3-14=-1229/0, 4-13=0/1290, 5-10=-1690/0, 6-10=0/1112, 6-8=-1424/0

- NOTES- (5-8)
- Unbalanced floor live loads have been considered for this design.
  - Load case(s) 1, 2, 3, 4, 5, 6 has/have been modified. Building designer must review loads to verify that they are correct for the intended use of this truss.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION. Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

- LOAD CASE(S) Standard
- Dead + Floor Live (balanced): Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 8-17=-8, 1-7=-80  
 Concentrated Loads (lb)  
 Vert: 3=-960
  - Dead: Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 8-17=-8, 1-7=-80  
 Concentrated Loads (lb)  
 Vert: 3=-960



1/4/2024

Warning!—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F107A	FLOOR	4	1	Job Reference (optional) # 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:28 2024 Page 2  
ID:1YrqHYj0sGK239HELXZ6g?zynRG-yeAjj72b78yrGnqv0YLIVr9F\_?Vhc68KE69NXhzyiH

**LOAD CASE(S)** Standard

- 3) 1st chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-8, 1-5=-80, 5-7=-16
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 4) 2nd chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-8, 1-4=-16, 4-7=-80
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 5) 3rd chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-8, 1-5=-80, 5-7=-16
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 6) 4th chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 8-17=-8, 1-4=-16, 4-7=-80
  - Concentrated Loads (lb)
    - Vert: 3=-960




1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job 23-B565-F01	Truss F108	Truss Type Floor Supported Gable	Qty 1	Ply 1	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC Job Reference (optional) <b># 43947</b>
--------------------	---------------	-------------------------------------	----------	----------	---

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:29 2024 Page 1  
ID:YrqHYj0sGK239HELXZ6g?zynRG-Qqk5wT3DuS4itxP6aFs\_23hbBO?kLITUSmux37zxiyG



Scale = 1:8.5

Plate Offsets (X,Y)-- [1:Edge,0-1-8], [2:0-1-8,Edge], [4:Edge,0-1-8]

LOADING (psf)	SPACING-	2-0-0	CSI.	DEFL.	in	(loc)	l/defl	L/d	PLATES	GRIP
TCLL 40.0	Plate Grip DOL	1.00	TC 0.05	Vert(LL)	n/a	-	n/a	999	MT20	244/190
TCDL 10.0	Lumber DOL	1.00	BC 0.01	Vert(CT)	n/a	-	n/a	999		
BCLL 0.0	Rep Stress Incr	YES	WB 0.03	Horz(CT)	0.00	4	n/a	n/a		
BCDL 5.0	Code IRC2021/TPI2014		Matrix-P							
									Weight: 15 lb	FT = 20%F, 11%E

**LUMBER-**  
TOP CHORD 2x4 SP No.1(flat)  
BOT CHORD 2x4 SP No.1(flat)  
WEBS 2x4 SP No.3(flat)  
OTHERS 2x4 SP No.3(flat)

**BRACING-**  
TOP CHORD Structural wood sheathing directly applied or 2-2-6 oc purlins, except end verticals.  
BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 4=16/2-2-6 (min. 0-1-8), 6=55/2-2-6 (min. 0-1-8), 5=136/2-2-6 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.

**NOTES-** (6-9)

- Gable requires continuous bottom chord bearing.
- Truss to be fully sheathed from one face or securely braced against lateral movement (i.e. diagonal web).
- Gable studs spaced at 1-4-0 oc.
- Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
- CAUTION. Do not erect truss backwards.
- Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
- Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
- Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
- SEE BCSI-B3 SUMMARY SHEET - PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard




1/4/2024


**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F109	FLOOR	1	1	
Job Reference (optional)					# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:30 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?zynRG-u0IU7p4rfmCZV5\_I8zNDaGEbAo9J409dhQeUbZzxiyF



Scale = 1:17.6



4-8-0	4-9-8 5-3-8	5-9-85-11-0	6-11-0	7-11-0	10-7-2
4-8-0	0-1-8 0-6-0	0-6-0 0-1-8	1-0-0	1-0-0	2-8-2
Plate Offsets (X,Y)-- [1:Edge,0-1-8], [4:0-1-8,Edge], [5:0-1-8,Edge], [6:0-1-8,Edge], [10:0-3-0,0-0-0], [16:Edge,0-1-8]					

LOADING (psf)	SPACING-	CSI.	DEFL.	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.74	in (loc) l/defl L/d	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.75	Vert(LL) -0.05 11-12 >999 480		
BCLL 0.0	Lumber DOL 1.00	WB 0.77	Vert(CT) -0.20 11-12 >630 360		
BCDL 5.0	Rep Stress Incr NO	Matrix-SH	Horz(CT) 0.02 7 n/a n/a		
	Code IRC2021/TPI2014			Weight: 65 lb	FT = 20%F, 11%E

LUMBER-	BRACING-
TOP CHORD 2x4 SP No.1(flat)	TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.
BOT CHORD 2x4 SP SS(flat)	BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.
WEBS 2x4 SP No.3(flat)	

**REACTIONS.** (lb/size) 16=993/0-4-8 (min. 0-1-8), 7=871/0-7-14 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-16=-984/0, 7-17=-796/0, 6-17=-795/0, 1-2=-1183/0, 2-3=-3111/0, 3-4=-3735/0, 4-5=-2550/0, 5-6=-894/0  
 BOT CHORD 14-15=0/2253, 13-14=0/2238, 12-13=0/3735, 11-12=0/2550, 10-11=0/2550, 9-10=0/2550  
 WEBS 4-11=-1017/0, 5-10=0/979, 1-15=0/1484, 2-15=-1392/0, 2-13=0/1090, 3-13=-1109/0, 4-12=0/1615, 5-9=-2065/0, 6-9=0/1127

- NOTES-** (5-8)
- Unbalanced floor live loads have been considered for this design.
  - Load case(s) 1, 2, 3, 4, 5, 6 has/have been modified. Building designer must review loads to verify that they are correct for the intended use of this truss.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION. Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard  
 1) Dead + Floor Live (balanced): Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 7-16=-8, 1-6=-80  
 Concentrated Loads (lb)  
 Vert: 3=-960  
 2) Dead: Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 7-16=-8, 1-6=-80  
 Concentrated Loads (lb)  
 Vert: 3=-960



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F109	FLOOR	1	1	Job Reference (optional) # 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:30 2024 Page 2  
ID:YrqHYj0sGK239HELXZ6g?zynRG-u0IU7p4rfmCZV5\_I8zNDaGEbAo9J409dhQeUbZzxiyF

**LOAD CASE(S)** Standard

- 3) 1st chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 7-16=-8, 1-5=-80, 5-6=-16
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 4) 2nd chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 7-16=-8, 1-4=-16, 4-6=-80
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 5) 3rd chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 7-16=-8, 1-5=-80, 5-6=-16
  - Concentrated Loads (lb)
    - Vert: 3=-960
- 6) 4th chase Dead: Lumber Increase=1.00, Plate Increase=1.00
  - Uniform Loads (plf)
    - Vert: 7-16=-8, 1-4=-16, 4-6=-80
  - Concentrated Loads (lb)
    - Vert: 3=-960



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 Guide to *Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F110	Floor	2	1	# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:31 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?zynRG-NDrsL95TQ3KQ7FZUiguS7UmtwCZ1pcZnw4N17?zxiyE



Scale = 1:17.3




Plate Offsets (X,Y)-- [3:0-1-8,Edge], [4:0-1-8,Edge], [13:Edge,0-1-8]

LOADING (psf)	SPACING-	CSI.	DEFL.	in (loc)	l/defl	L/d	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.29	Vert(LL)	-0.07	10-11	>999	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.46	Vert(CT)	-0.09	10-11	>999		
BCLL 0.0	Lumber DOL 1.00	WB 0.25	Horz(CT)	0.01	7	n/a		
BCDL 5.0	Rep Stress Incr YES	Matrix-SH						
	Code IRC2021/TPI2014						Weight: 54 lb	FT = 20%F, 11%E

**LUMBER-**  
 TOP CHORD 2x4 SP No.1(flat)  
 BOT CHORD 2x4 SP No.1(flat)  
 WEBS 2x4 SP No.3(flat)

**BRACING-**  
 TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
 BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 13=455/0-4-8 (min. 0-1-8), 7=450/0-7-14 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-13=-451/0, 1-2=-341/0, 2-3=-971/0, 3-4=-1096/0, 4-5=-724/0  
 BOT CHORD 11-12=0/794, 10-11=0/1096, 9-10=0/1096, 8-9=0/1096, 7-8=0/388  
 WEBS 3-11=-252/0, 2-12=-589/0, 1-12=0/517, 4-8=-476/0, 5-8=0/437, 5-7=-583/0

- NOTES-** (4-7)
- Unbalanced floor live loads have been considered for this design.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION. Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F111	FLOOR	1	1	# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:32 2024 Page 1  
 ID:YrqHYj0sGK239HELXZ6g?zynRG-rPPEYV55BNSHK08hFNQhfhJtrcoYYtkw9k7bgSzxyD



Scale = 1:20.2




Plate Offsets (X,Y)-- [4:0-1-8,Edge], [5:0-3-0,Edge], [7:0-1-8,0-0-8], [12:0-3-0,0-0-0], [14:0-3-0,Edge], [16:0-3-0,Edge]					
<b>LOADING</b> (psf)	<b>SPACING-</b> 1-7-3	<b>CSI.</b>	<b>DEFL.</b> in (loc) l/defl L/d	<b>PLATES</b>	<b>GRIP</b>
TCLL 40.0	Plate Grip DOL 1.00	TC 0.99	Vert(LL) -0.03 13 >999 480	MT20	244/190
TCDL 10.0	Lumber DOL 1.00	BC 0.96	Vert(CT) -0.24 13-14 >493 360	MT20HS	187/143
BCLL 0.0	Rep Stress Incr NO	WB 0.92	Horz(CT) 0.02 10 n/a n/a		
BCDL 5.0	Code IRC2021/TPI2014	Matrix-SH			Weight: 98 lb FT = 20%F, 11%E


<b>LUMBER-</b>	<b>BRACING-</b>
TOP CHORD 2x4 SP No.1(flat)	TOP CHORD Structural wood sheathing directly applied or 4-3-4 oc purlins, except end verticals.
BOT CHORD 2x4 SP SS(flat)	BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing, Except: 6-0-0 oc bracing: 10-11,9-10.
WEBS 2x4 SP No.3(flat) *Except* W2,W4: 2x4 SP No.2(flat)	

**REACTIONS.** All bearings 2-2-6 except (jt=length) 17=0-4-8.  
 (lb) - Max Uplift All uplift 100 lb or less at joint(s) 9  
 Max Grav All reactions 250 lb or less at joint(s) 8 except 17=1514(LC 1), 10=1500(LC 1), 10=1500(LC 1)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
 TOP CHORD 1-17=-1498/0, 1-2=-2099/0, 2-3=-5576/0, 3-4=-6521/0, 4-5=-3968/0, 5-6=-975/0  
 BOT CHORD 15-16=0/3976, 14-15=0/6521, 13-14=0/3968, 12-13=0/3968, 11-12=0/3968  
 WEBS 3-14=-1268/0, 6-10=-1065/0, 4-13=-1184/0, 5-12=0/1221, 1-16=0/2523, 2-16=-2327/0, 2-15=0/1985, 3-15=-1606/0, 4-14=0/3250, 5-11=-3681/0, 6-11=0/1574

- NOTES-** (7-10)
- 1) Unbalanced floor live loads have been considered for this design.
  - 2) All plates are MT20 plates unless otherwise indicated.
  - 3) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 100 lb uplift at joint(s) 9.
  - 4) Load case(s) 1, 2, 3, 4, 5, 6 has/have been modified. Building designer must review loads to verify that they are correct for the intended use of this truss.
  - 5) Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - 6) CAUTION, Do not erect truss backwards.
  - 7) Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - 8) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - 9) Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - 10) SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard  
 1) Dead + Floor Live (balanced): Lumber Increase=1.00, Plate Increase=1.00  
 Uniform Loads (plf)  
 Vert: 8-17=-8, 1-7=-80



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F111	FLOOR	1	1	Job Reference (optional) # 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:32 2024 Page 2  
ID:YrqHYj0sGK239HELXZ6g?zynRG-rPPEYV55BNSHkO8hFNQhfhJtrcoYYtkw9k7bgSzxiyD

**LOAD CASE(S)** Standard

- Concentrated Loads (lb)  
Vert: 3=-2000
- 2) Dead: Lumber Increase=1.00, Plate Increase=1.00  
Uniform Loads (plf)  
Vert: 8-17=-8, 1-7=-80  
Concentrated Loads (lb)  
Vert: 3=-2000
- 3) 1st chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00  
Uniform Loads (plf)  
Vert: 8-17=-8, 1-5=-80, 5-6=-16, 6-7=-80  
Concentrated Loads (lb)  
Vert: 3=-2000
- 4) 2nd chase Dead + Floor Live (unbalanced): Lumber Increase=1.00, Plate Increase=1.00  
Uniform Loads (plf)  
Vert: 8-17=-8, 1-4=-16, 4-7=-80  
Concentrated Loads (lb)  
Vert: 3=-2000
- 5) 3rd chase Dead: Lumber Increase=1.00, Plate Increase=1.00  
Uniform Loads (plf)  
Vert: 8-17=-8, 1-5=-80, 5-6=-16, 6-7=-80  
Concentrated Loads (lb)  
Vert: 3=-2000
- 6) 4th chase Dead: Lumber Increase=1.00, Plate Increase=1.00  
Uniform Loads (plf)  
Vert: 8-17=-8, 1-4=-16, 4-7=-80  
Concentrated Loads (lb)  
Vert: 3=-2000



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 Guide to *Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.





Plate Offsets (X,Y)-- [3:0-1-8,Edge], [4:0-1-8,Edge], [9:0-1-8,Edge], [10:0-1-8,Edge], [12:0-1-8,Edge], [28:Edge,0-1-8]					
<b>LOADING</b> (psf)	<b>SPACING-</b> 1-4-0	<b>CSI.</b>	<b>DEFL.</b> in (loc) l/defl L/d	<b>PLATES</b>	<b>GRIP</b>
TCLL 40.0	Plate Grip DOL 1.00	TC 0.29	Vert(LL) -0.07 15-16 >999 480	MT20	244/190
TCDL 10.0	Lumber DOL 1.00	BC 0.45	Vert(CT) -0.09 15-16 >999 360		
BCLL 0.0	Rep Stress Incr YES	WB 0.27	Horz(CT) 0.02 13 n/a n/a		
BCDL 5.0	Code IRC2021/TPI2014	Matrix-SH			Weight: 119 lb FT = 20%F, 11%E

**LUMBER-**  
 TOP CHORD 2x4 SP No.1(flat)  
 BOT CHORD 2x4 SP No.1(flat)  
 WEBS 2x4 SP No.3(flat)

**BRACING-**  
 TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
 BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing, Except: 6-0-0 oc bracing: 22-23,21-22,20-21,18-20.

**REACTIONS.** (lb/size) 28=373/0-7-14 (min. 0-1-8), 13=373/0-7-14 (min. 0-1-8), 21=980/0-4-8 (min. 0-1-8)  
 Max Grav 28=394(LC 10), 13=395(LC 7), 21=980(LC 1)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.

**TOP CHORD** 28-29=-391/0, 1-29=-391/0, 13-30=-391/0, 12-30=-391/0, 1-2=-346/0, 2-3=-893/0, 3-4=-1013/0, 4-5=-723/2, 5-6=-3/332, 6-7=-3/332, 7-8=0/386, 8-9=-700/27, 9-10=-1013/0, 10-11=-916/0, 11-12=-390/0

**BOT CHORD** 26-27=0/735, 25-26=0/1013, 24-25=0/1013, 23-24=0/1013, 22-23=-119/458, 21-22=-678/0, 20-21=-681/0, 19-20=-151/420, 18-19=-151/420, 17-18=0/1013, 16-17=0/1013, 15-16=0/1013, 14-15=0/774

**WEBS** 7-21=-963/0, 2-27=-506/0, 1-27=0/465, 4-23=-450/0, 5-23=0/397, 5-22=-625/0, 7-22=0/570, 9-18=-482/0, 8-18=0/418, 8-20=-630/0, 7-20=0/537, 11-14=-500/0, 12-14=0/493

- NOTES-** (4-7)
- 1) Unbalanced floor live loads have been considered for this design.
  - 2) Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - 3) CAUTION, Do not erect truss backwards.
  - 4) Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - 5) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - 6) Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - 7) SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI I-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 0.0004 HONEYCUTT HILLS   69 SHELBY MEADOW LANE ANGIER, NC
23-B565-F01	F113	Floor Supported Gable	1	1	# 43947

Run: 8.430 s Feb 12 2021 Print: 8.430 s Feb 12 2021 MiTek Industries, Inc. Sun Jan 7 16:00:35 2024 Page 1  
 ID: IYrqHYj0sGK239HELXZ6g?zynRG-F\_5NBW8\_UlqsbstGxWzOHKxdap26ISvMriLFGnzxiYA

0-1-8

0-1-8

Scale = 1:39.7




Plate Offsets (X,Y)-- [11:0-1-8,Edge], [32:0-1-8,Edge], [40:Edge,0-1-8]		23-10-12		23-10-12		23-10-12	
<b>LOADING</b> (psf)	<b>SPACING-</b>	2-0-0	<b>CSI.</b>	<b>DEFL.</b>	in (loc)	l/defl	L/d
TCLL 40.0	Plate Grip DOL	1.00	TC 0.06	Vert(LL)	n/a	-	n/a 999
TCDL 10.0	Lumber DOL	1.00	BC 0.01	Vert(CT)	n/a	-	n/a 999
BCLL 0.0	Rep Stress Incr	YES	WB 0.03	Horz(CT)	0.00	21	n/a
BCDL 5.0	Code IRC2021/TPI2014		Matrix-SH				
							<b>PLATES</b>
							MT20
							<b>GRIP</b>
							244/190
							Weight: 101 lb FT = 20%F, 11%E

<b>LUMBER-</b>	<b>BRACING-</b>
TOP CHORD 2x4 SP No.1(flat)	TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.
BOT CHORD 2x4 SP No.1(flat)	BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.
WEBS 2x4 SP No.3(flat)	
OTHERS 2x4 SP No.3(flat)	

**REACTIONS.** All bearings 23-10-12.  
 (lb) - Max Grav All reactions 250 lb or less at joint(s) 40, 21, 39, 38, 37, 36, 35, 34, 33, 32, 31, 30, 28, 27, 26, 25, 24, 23, 22

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.



- NOTES-** (5-8)
- Gable requires continuous bottom chord bearing.
  - Truss to be fully sheathed from one face or securely braced against lateral movement (i.e. diagonal web).
  - Gable studs spaced at 1-4-0 oc.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard



1/4/2024

**Warning!**—Verify design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



LOADING (psf)	SPACING-	CSI.	DEFL.	PLATES	GRIP
TCLL 40.0	1-7-3	TC 0.22	in (loc) l/defl L/d	MT20	244/190
TCDL 10.0	Plate Grip DOL 1.00	BC 0.42	Vert(LL) -0.07 11-12 >999 480		
BCLL 0.0	Lumber DOL 1.00	WB 0.31	Vert(CT) -0.09 11 >999 360		
BCDL 5.0	Rep Stress Incr YES	Matrix-SH	Horz(CT) 0.02 7 n/a n/a		
	Code IRC2021/TPI2014			Weight: 62 lb	FT = 20%F, 11%E

**LUMBER-**  
TOP CHORD 2x4 SP No.1(flat)  
BOT CHORD 2x4 SP No.1(flat)  
WEBS 2x4 SP No.3(flat)

**BRACING-**  
TOP CHORD Structural wood sheathing directly applied or 6-0-0 oc purlins, except end verticals.  
BOT CHORD Rigid ceiling directly applied or 10-0-0 oc bracing.

**REACTIONS.** (lb/size) 14=518/0-7-14 (min. 0-1-8), 7=523/0-4-8 (min. 0-1-8)

**FORCES.** (lb) - Max. Comp./Max. Ten. - All forces 250 (lb) or less except when shown.  
TOP CHORD 14-15=-516/0, 1-15=-515/0, 6-7=-520/0, 1-2=-461/0, 2-3=-1227/0, 3-4=-1470/0, 4-5=-1227/0, 5-6=-459/0  
BOT CHORD 12-13=0/975, 11-12=0/1470, 10-11=0/1470, 9-10=0/1470, 8-9=0/977  
WEBS 3-12=-390/0, 2-12=0/331, 2-13=-670/0, 1-13=0/619, 4-9=-390/0, 5-9=0/331, 5-8=-674/0, 6-8=0/641

- NOTES-** (4-7)
- Unbalanced floor live loads have been considered for this design.
  - Recommend 2x6 strongbacks, on edge, spaced at 10-0-0 oc and fastened to each truss with 3-10d (0.131" X 3") nails. Strongbacks to be attached to walls at their outer ends or restrained by other means.
  - CAUTION. Do not erect truss backwards.
  - Graphical bracing representation does not depict the size, type or the orientation of the brace on the member. Symbol only indicates that the member must be braced.
  - Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.
  - Web bracing shown is for lateral support of individual web members only. Refer to BCSI - Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses for additional bracing guidelines, including diagonal bracing.
  - SEE BCSI-B3 SUMMARY SHEET- PERMANENT RESTRAINING/BRACING OF CHORDS & WEB MEMBERS FOR RECOMMENDED MINIMUM BRACING REQUIREMENTS OF TOP CHORD, BOTTOM CHORD, AND WEB PLANES. IN ADDITION TO THESE MINIMUM GUIDELINES, ALWAYS CONSULT THE PROJECT ARCHITECT OR ENGINEER FOR ADDITIONAL BRACING CONSIDERATIONS.

**LOAD CASE(S)** Standard



1/4/2024

**Warning !—Verify design parameters and read notes before use.** This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 *Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.