

BBO

15' 10"

Plumbing Drop Notes

. Plumbing drop locations shown are NOT exact. 2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses

3. Adjust spacing as needed not to exceed 24"oc.

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of stud unless noted otherwise

3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

= 2244.55 sq.ft. Roof Area = 66.51 ft. Ridge Line = 0 ft. Hip Line = 183.29 ft. Horiz. OH = 175.61 ft. Raked OH Decking = 77 sheets

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss 🛕 (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

WALL SCHEDULE					
1st Floor Walls					
2nd Floor Walls					
Non-Bearing Walls					
Garage Walls Dropped					

Nail Information		Connector Information				
Truss	Header	Supported Member	Qty	Manuf	Product	Sym
16d/3-1/2"	16d/3-1/2"	NA	43	USP	HUS410	
10d/3"	10d/3"	NA	1	USP	IHFI1714	0
16d /3-1/2"	16d /3-1/2"	NA	0	USP	THDH612	6

Products							
Net Qty	Plies	Product	Length	PlotID			
1	1	1-3/4"x 14" LVL Kerto-S	12' 0"	FB2			
2	2	1-3/4"x 14" LVL Kerto-S	10' 0"	FB3			
2	2	1-3/4"x 14" LVL Kerto-S	6' 0"	FB1			
3	3	1-3/4"x 18" LVL Kerto-S	22' 0"	FB4			
3	3	1-3/4"x 18" LVL Kerto-S	16' 0"	FB5			
2	2	2x10 SPF No.2	8' 0"	BBO			

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.con

JOB NAME

соттесн

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309

Phone: (910) 864-8787 Fax: (910) 864-4444

g reactions less than or equal to 3000# are to comply with the prescriptive Code ments. The contractor shall refer to the d Tables (derived from the prescriptive Coments) to determine the minimum foundated number of wood studs required to suppos greater than 3000# but not greater than

Signature Johnnie Baggett

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF

2550 1

5100 2

7650 3

10200 4

12750 5

15300 6

1700 1

3400 2

5100 3

6800 4

8500 5

10200 6

11900 7 13600 8 15300 9

Lillington / Harnett

CITY / CO.

20 Eagle (

Creek

@ Neills

The Holly -

SEAL DATE

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

New Home Inc

BUILDER

Johnnie Baggett

3400 1

6800 2

10200 3

13600 4

17000 5

Johnnie Baggett

DRAWN BY

B0824-4628

QUOTE;

10/28/24

DATE REV.

Paul Hawkins

20' 2"