General Notes:

** CUTTING OR DRILLING OF COMPONENTS SHOULD NOT BE DONE WITHOUT CONTACTING COMPONENT SUPPLIER FIRST. CUSTOMER TAKES FULL RESPONSIBILITY FOR COMPONENTS IF CUT BEFORE AUTHORIZATION.

** ALL POINT LOADS FROM ABOVE MUST BE TRANSFERRED TO BEARING FROM UNDER SIDE OF SHEATHING.

** ALL BEARING POINTS MUST BE INSTALLED PRIOR TO SETTING ANY COMPONENTS.

** DAMAGED COMPONENTS SHOULD NOT BE INSTALLED UNLESS TOLD TO BY THE COMPONENT PLANT.

** FRAMER MUST REFER TO PLANS WHILE SETTING COMPONENTS.



Products					
PlotID	Length	Product	Plies	Net Qty	Fab Type
FB6-2	30-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB3-3	30-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	3	3	FF
FB7-2	16-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB2-2	16-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB8-2	16-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB9-2	16-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB5-2	12-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB1-2	10-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB11-2	6-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB10-2	4-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF
FB4-2	4-00-00	2.0 RigidLam DF LVL 1-3/4 x 16	2	2	FF

Connector Summary		
Qty	Manuf	Product
1	Simpson	HGUS474
1	Simpson	HUI414
2		HWPH3.56/16

Truss Connector Total List		
Manuf	Product	Qty
Simpson	THAA22	39
Simpson	THAC422	17

Note: All LVL/Steel Beams and LVL to LVL and LVL to Steel connections sized per EOR.

Note: F4 trusses are 22" deep to remove excess deflection. Lower garage walls 6" from main house walls to match floor heights





Truss Drawing Left End Indicator

** TRUSS TO TRUSS CONNECTIONS ARE TOE-NAILED, UNLESS NOTED OTHERWISE.

** DIMENSIONS ARE READ AS: FOOT-INCH-SIXTEENTH.

** GIRDERS MUST BE FULLY CONNECTED TOGETHER PRIOR TO ADDING ANY LOADS.

Revisions	
00/00/00	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor systems and for the overall structure. The design of the truss support structure including headers, beams, walls, columns and foundations is the responsibility of the building designer. For general guidance regarding the bracing consult "Bracing of Wood Trusses" available from the Truss Plate Institute, 583 D'Onofrio Drive: Madison, WI 53179

CARTER Lumber

CRH Homes LLC

Dalton

Floor **PLACEMENT PLAN**

Scale: ***NTS***

Date: 2/22/2024

Designer: Mike Finch

Project Number: **22080120**

Sheet Number: **1/1**

** TRIANGULAR SYMBOL NEAR END OF TRUSS INDICATES LEFT END OF TRUSS AS SHOWN ON INDIVIDUAL TRUSS DRAWINGS.

** PLUMBING DROPS NOTED ARE IN THE APPROXIMATE LOCATIONS PER PLAN. BUILDER TO VERIFY LOCATIONS BEFORE SETTING TRUSSES.

** REFER TO FINAL TRUSS ENGINEERING SHEETS FOR PLY TO PLY CONNECTIONS.