Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.

2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.

3. Adjust spacing as needed not to exceed 19.2"oc U.N.O..

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of stud unless noted otherwise
3. All exterior wall to truss dimensions are to face of stud unless noted otherwise


All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss ▲ (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

WALL SCHEDULE						
1st Floor Walls						
Foundation Walls						
Non-Bearing Walls						
Garage Walls Dropped						
g						

Nail Information			Connector Information				
	Truss	Header	Supported Member	Qty	Manuf	Product	Sym
	16d/3-1/2"	16d/3-1/2"	NA	6	USP	HUS410	
	10d/3"	10d/3"	Varies	11	USP	MSH422	

Products							
Net Qty	Plies	Product	Length	PlotID			
4	2	1-3/4"x 14" LVL Kerto-S	7' 0"	2FB1			
2	2	1-3/4"x 14" LVL Kerto-S	4' 0"	2FB2			
3	3	1-3/4"x 23-7/8" LVL Kerto-S	22' 0"	2FB3			



= Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE

QUOTE;

JOB NAME

COMTECH

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

dearing reactions less than or equal to 3000# are eemed to comply with the prescriptive Code equirements. The contractor shall refer to the ttached Tables (derived from the prescriptive Code equirements) to determine the minimum foundation ize and number of wood studs required to support eactions greater than 3000# but not greater than 5000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attached ables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Signature Johnnie Baggett

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R502.5(1) & (b))

NUMBER OF JACK STUDS REQUIRED @ EA END OF

HEADER/GIRDER

END REACTION (UP TO) REQ'D STUDS FOR (3) PLY HEADER

2550 1

5100 2

7650 3

10200 4

12750 5

15300 6

1700 1

3400 2

5100 3

6800 4

8500 5

10200 6

11900 7 13600 8 15300 9

Lilllington / Harnett

CITY / CO.

New Home Inc

BUILDER

Creek

ADDRESS

END REACTION
(UP TO)
REQ'D STUDS FOR
(4) PLY HEADER

3400 1

6800 2

10200 3

13600 4

17000 5

Johnnie Baggett

DRAWN BY

4/15/24

DATE REV.

MODEL

Si

3rd

Paul Hawkins

SALES REP.

Johnnie Baggett