

Dimension Notes

All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
 All interior wall dimensions are to face of stud unless noted otherwise
 All exterior wall to truss dimensions are to face of stud unless noted otherwise

Roof Area = 2265.42 sq.ft. Ridge Line = 86.64 ft. Hip Line = 0 ft. Horiz. OH = 155.84 ft. Raked OH = 202.8 ft. Decking = 78 sheets

All Walls Shown Are

WALL SCHEDULE 1st Floor Walls

□□□□□ Non-Bearing Walls

NA


MSH422 USP 21 Varies

USP 4

HUS410

2nd Floor Walls

10d/3"



соттесн **ROOF & FLOOR TRUSSES & BEAMS** 

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are leemed to comply with the prescriptive Code equirements. The contractor shall refer to the attached Tables ( derived from the prescriptive Code equirements ) to determine the minimum foundation size and number of wood studs required to support eactions greater than 3000# but not greater than 15000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attached fables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Signature Johnnie Baggett

Johnnie Baggett

LOAD CHART FOR JACK STUDS

	(B	ASED O	N TABLES	5 R502.	5(1) & (l	o))	
NUM	ABER C		STUDS R			A END OF	=
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END RE <i>AC</i> TION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
1700	1		2550	1		3400	1
3400	2		5100	2		6800	2
5100	3		7650	3		10200	3
6800	4		10200	4		13600	4
8500	5		12750	5		17000	5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

CITY / CO.	CITY / CO.   Lillington / Harnett
ADDRESS	XXX Duncans Creek Road
WODEL	Roof
DATE REV.	4/25/24
DRAWN BY	DRAWN BY Johnnie Baggett
SALES REP.	Paul Hawkins

Creek New Home Inc. 80523-2125 3/2/22 JOB NAME SEAL DATE **QUOTE**# BUILDER PLAN

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com