

All Walls Shown Are Considered Load Bearing

= 1st Level Wall

= 2nd Level Wall

HUS26	USP	6	NA	16d/3-1/2"	16d/3-1/2"
JUS26	USP	6	NA	10d/3"	10d/3"

Truss Placement Plan SCALE: 1/4"=1'

JILDER A & G Residential		CITY	/ / <b>CO</b> .	7	Coats / Harne	:††		
	J	US26	USP	6	NA	10d/3"	10d/3"	
		10526	057	О	INA	160/3-1/2	160/3-1/2	

\_\_\_ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards

LOAD CHART FOR JACK STUDS								
(BASED ON TABLES R502.5(1) & (b))								
NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER								
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER	
1700	1		2550	1		3400	1	
3400	2		5100	2		6800	2	
5100	3		7650	3		10200	3	
6800	4		10200	4		13600	4	
8500	5		12750	5		17000	5	
10200	6		15300	6				
11900	7							
13600	8							
15300	9							

BUILDER	A & G Residential	CITY / CO.	Coats / Harnett	
JOB NAME	Lot 19 Turlington Acres	ADDRESS	96 Regis Lane	sheets for is respons the overal walls, and regarding
		MODEL	Roof	or online  Bearing prescript
		DATE REV.	05/01/25	( derived foundation than 3000 be retained
QUOTE#		DRAWN BY	Marshall Naylor	specified retained
<b>JOB #</b> J0425-1937		SALES REP.	Marshall Naylor	Signa

IS A TRUSS PLACEMENT DIAGRAM ONLY.

Marshall Naylor Marshall Naylor



Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444