



# ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park  
 Fayetteville, N.C. 28309  
 Phone: (910) 864-8787  
 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables ( derived from the prescriptive Code requirements ) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signature **Johnnie Baggett**  
**Johnnie Baggett**

### LOAD CHART FOR JACK STUDS


(BASED ON TABLES R502.5(1) & (b))  
 NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

END REACTION (UP TO)	REQ. D. STUDS FOR (1) FLY HEADER	END REACTION (UP TO)	REQ. D. STUDS FOR (1) FLY HEADER	END REACTION (UP TO)	REQ. D. STUDS FOR (1) FLY HEADER
1700	1	2550	1	3400	1
3400	2	5100	2	6800	2
5100	3	7650	3	10200	3
6800	4	10200	4	13600	4
8500	5	12750	5	17000	5
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

CITY / CO.	ADDRESS	MODEL	DATE REV.	DRAWN BY	SALES REP.
Lillington / Harnett	508 Duncan Creek Road	I Joist Crawl	9/17/24	Johnnie Baggett	Paul Hawkins

BUILDER	JOB NAME	PLAN	SEAL DATE	QUOTE #	JOB #
New Home Inc.	Lot 153 Duncans Creek	The Brunswick - Craftsman	Seal Date	B0224-1090	J0924-5122

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com



**Plumbing Drop Notes**  
 1. Plumbing drop locations shown are NOT exact.  
 2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.  
 3. Adjust spacing as needed not to exceed 19.2' oc.

**Dimension Notes**  
 1. All exterior wall to wall dimensions are to face of stud unless noted otherwise  
 2. All interior wall dimensions are to face of stud unless noted otherwise  
 3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss ▲  
 (Reference Engineered Truss Drawing)  
 Do Not Erect Trusses Backwards

Products				
Net Qty	Plies	Product	Length	PlotID
12	1	11 7/8" NI-40x	28' 0"	FJ1
1	1	11 7/8" NI-40x	20' 0"	FJ2
12	2	11 7/8" NI-40x	18' 0"	FJ3
5	1	11 7/8" NI-40x	14' 0"	FJ4
8	1	11 7/8" NI-40x	10' 0"	FJ5
15	1	11 7/8" NI-40x	8' 0"	FJ6
1	1	11 7/8" NI-40x	6' 0"	FJ7
2	2	1-3/4"x 11-7/8" LVL Kerto-S	28' 0"	FB1
2	2	1-3/4"x 11-7/8" LVL Kerto-S	13' 0"	FB2
8	1	1 1/8" x 11 7/8" Rim Board	12' 0"	RIM1
6	1	1 1/8" x 11 7/8" Rim Board	12' 0"	RIM1
24	1	11 7/8" NI-40x	2' 0"	Bk1

Truss Placement Plan  
 SCALE: NTS

▲ = Indicates Left End of Truss  
 (Reference Engineered Truss Drawing)  
 Do NOT Erect Truss Backwards