

All Walls Shown Are Considered Load Bearing

▲= Denotes Left End of Truss (Reference Engineered Truss Drawing)

Dimension Notes
1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise 2. All interior wall dimensions are to face of stud unless noted otherwise 3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

	Conne	Nail Information				
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS179	USP	1	NA	10d/3"	10d/3"
	MSH422	USP	10	Varies	10d/3"	10d/3"
	JUS414	USP	2	NA	16d/3-1/2"	16d/3-1/2"

Products								
PlotID	Length	Product	Plies	Net Qty				
1.75x14" LVL	8' 0"	1-3/4"x 14" LVL Kerto-S	1	1				
(2) 1.75" x 14" LVL	8' 0"	1-3/4"x 14" LVL Kerto-S	2	2				
1 75x14" VI	5' 0"	1-3/4"x 14" I VI Kerto-S	1	1				

соттесн **ROOF & FLOOR TRUSSES & BEAMS** Reilly Road Industrial Park

Fayetteville, N.C. 28309 Phone: (910) 864-8787

Fax: (910) 864-4444

ature Hampton Horrocks

Hampton Horrocks

(BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

LOAD CHART FOR JACK STUDS

1700 1 3400 2 5100 3 6800 4 8500 5 10200 6 11900 7 13600 8 15300 9 2550 1 5100 2 7650 3 10200 4 12750 5 15300 6 3400 1 6800 2 10200 3 13600 4 17000 5