

Dimension Notes All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
 All interior wall dimensions are to face of frame wall unless noted otherwise All exterior wall to truss dimensions are to face of frame wall unless noted otherwise

Roof Area = 1961.89 sq.ft. Ridge Line = 69.9 ft. Hip Line = 10.29 ft. Horiz. OH = 144.14 ft. Raked OH = 175.31 ft. Decking = 67 sheets

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

WALL SCHEDULE
1st Floor Brg. Wall
2nd Floor Brg. Wall
□□□□□ Non-Bearing Walls

Connector Information					Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss	
	HUS26	USP	25	Varies	16d/3-1/2"	16d/3-1/2"	
	THD26-2	USP	1	Varies	16d/3-1/2"	10d/3"	

		Products			
PlotID	Length	Product	Plies	Net Qty	Fab Type
GDH	21-00-00	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF
BM2	22-00-00	1-3/4"x 23-7/8" LVL Kerto-S	2	2	FF

## соттесн **ROOF & FLOOR TRUSSES & BEAMS**

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Anthony Williams

LOAD CHART FOR JACK STUDS

		J. 17 11	••••			0,00	_
(BASED ON TABLES R502.5(1) & (b))							
NUI	MBER C		STUDS F HEADER/			A END OF	=
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END RE <i>AC</i> TION (UP TO)	REQ'D STUDS FOR (4) PLY HEADER
1700	1		2550	1		3400	1
3400	2		5100	2		6800	2
5100	3		7650	3		10200	3
6800	4		10200	4		13600	4
8500	5		12750	5		17000	5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

>	Harnett County
55	122 Reece Dr. / Sanford, NC
•	Roof
REV.	11/4/24
V BY	Anthony Williams

ADDRES MODEL DATE RE DRAWN Signature Home Builders Clark 1960 / 170328B Lot 20 West Ridge J1124-5926 2/16/15 Ž JOB NAME SEAL DATE

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

BUILDER

QUOTE#

Truss Placement Plan SCALE: 1/4" = 1'