




THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual components to be incorporated into the building design as the specifier of the building design. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor systems and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding the design, consult "Bracing of Wood Truss" available from the Truss Plate Institute, 683 Donlin Drive, Madison, WI 53179.


Revisions	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name

FRAMER MUST REFER TO PLANS WHILE SETTING COMPONENTS. ** DAMAGED COMPONENTS SHOULD NOT BE INSTALLED UNLESS TOLD TO BY THE COMPONENT PLANT. ** ALL BEARING POINTS MUST BE INSTALLED PRIOR TO SETTING ANY COMPONENTS.
 ** TRIANGULAR SYMBOL NEAR END OF TRUSS INDICATES LEFT END OF TRUSS AS SHOWN ON INDIVIDUAL TRUSS DRAWINGS. ** PLUMBING DROPS NOTED ARE IN THE APPROXIMATE LOCATIONS PER PLAN. BUILDER TO VERIFY LOCATIONS BEFORE SETTING TRUSSES.
 ** REFER TO FINAL TRUSS ENGINEERING SHEETS FOR PLY TO PLY CONNECTIONS.



Qty	Product	Manuf	Truss Connector Total List
3	HHUS46	Simpson	
15	THA422	Simpson	
6	THAC422	Simpson	

PlotID	Product	Length	Products
FB1-2	2.1 Rigidlam SP LVL 1-3/4 x 24	22-00-00	
FB-2	2.1 Rigidlam SP LVL 1-3/4 x 18	14-00-00	
FB-2	2.1 Rigidlam SP LVL 1-3/4 x 14	8-00-00	
DB3-2	2.1 Rigidlam SP LVL 1-3/4 x 14	12-00-00	



General Notes:

** CUTTING OR DRILLING OF COMPONENTS SHOULD NOT BE DONE WITHOUT CONTACTING COMPONENT SUPPLIER FIRST. CUSTOMER TAKES FULL RESPONSIBILITY FOR COMPONENTS IF CUT BEFORE AUTHORIZATION. ** ALL POINT LOADS FROM ABOVE MUST BE TRANSFERRED TO BEARING FROM UNDER SIDE OF SHEATHING.