



ALL BEARING POINTS MUST BE INSTALLED PRIOR TO SETTING ANY COMPONENTS.



Products						
PlotID	Length	Product		Plies	Net Qty	Fab Type
BM5	20-00-00	2.1 RigidLam SP	LVL 1-3/4 x 11-7/8	3	3	FF
BM2	8-00-00	2.1 RigidLam SP	LVL 1-3/4 x 14	2	2	FF
BM4	6-00-00	2.1 RigidLam SP	LVL 1-3/4 x 14	1	1	FF
BM1	16-00-00	2.1 RigidLam SP	LVL 1-3/4 x 18	2	2	FF
BM3	30-00-00	2.1 RigidLam SP	LVL 1-3/4 x 20	2	2	FF



TRUSS TO TRUSS CONNECTIONS ARE TOE-NAILED UNLESS NOTED OTHERWISE

FLOOR PLACEMENT PLAN

CARTER

Lumber

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor systems and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding the bracing, consult "Bracing of Wood Truss" available from the Truss Plate Institute, 583 D'Onofrio Drive: Madison, WI 53179

Revisions	
00/00/00	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name
00/00/00	Name