

**ROOF & FLOOR TRUSSES & BEAMS** Reilly Road Industrial Park

Fayetteville, N.C. 28309 Phone: (910) 864-8787

NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER 3400 1 6800 2 10200 3 13600 4 17000 5

Marshall Naylor Marshall Naylor DRAWN BY

> J0625-3146 QUOTE;

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

(Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards

GDH-1 23-00-00 1-3/4"x 16" LVL Kerto-S 3