

Truss Placement Plan SCALE: 3/16" = 1'-0"

	Conne	ctor Info	rmati	ion	Nail Info	ormation
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS28	USP	5		16d/3-1/2	16d/3-1/2"

	Estir	mation	
Name	Selection	Formula	Calculation
Roof Area	1st Floor	Roof Area	3750.78
Roof Decking	1st Floor	Roof Decking	129

		BEAM LEGEND			
PlotID	Length	Product	Plies	Net Qty	Fab Type
BM1(flush)	10-00-08	1-3/4"x 9-1/4" LVL Kerto-S	2	2	FF
GDH 18' FL(dropped)	23-06-00	1-3/4"x 11-7/8" LVL Kerto-S	3	3	FF
GDH 12' FL	14-00-00	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF

Hatch Legend

= LOAD BEARING WALL HGT. @ 9-1-8

▲ = Denotes Left End of Truss (Reference Engineered Truss Drawing)

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs

соттесн
ROOF & FLOOR

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

TRUSSES & BEAMS

dearing reactions less than or equal to 3000# are eemed to comply with the prescriptive Code equirements. The contractor shall refer to the ttached Tables (derived from the prescriptive Code equirements) to determine the minimum foundation ize and number of wood studs required to support eactions greater than 3000# but not greater than 5000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attached ables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Sales Area

Sales Area

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF

		HEADER/	GIRDER	₹.		
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER		END REACTION (UP TO)	
1700	1	2550	1		3400	
3400	2	5100	2		6800	
5100	3	7650	3		10200)
6800	4	10200	4		13600)
8500	5	12750	5		17000)
10200	6	15300	6			
11900	7					
13600	8					
15300	9					

pment, Inc.	CITY / CO . Harnett Co.	Harnett Co.	
eserve	ADDRESS		
fied	MODEL	Roof	
	DATE REV . 08/2025	08/2025	
	DRAWN BY	DRAWN BY Lenny Norris	
	SALES REP.	SALES REP. Lenny Norris	

Weaver Develop JOB NAME

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

BUILDER