
Second Floor:



Products							
PlotID	Net Qty	Product	Length	Plies			
FJ1	14	14" PWI 205 or LPI 20Plus	37'0"	1			
FJ2	3	14" PWI 205 or LPI 20Plus	23' <i>0</i> "	1			
FJ3	6	14" PWI 205 or LPI 20Plus	22' <i>0</i> "	1			
FJ4	2	14" PWI 205 or LPI 20Plus	22' <i>0</i> "	2			
FJ5	9	14" PWI 205 or LPI 20Plus	21' <i>0</i> "	1			
FJ6	7	14" PWI 205 or LPI 20Plus	1 <i>8'0</i> "	1			
FJ7	ප	14" PWI 205 or LPI 20Plus	16'0"	1			
FJ8	2	14" PWI 205 or LPI 20Plus	8'O"	1			
FJ9	1	14" PWI 205 or LPI 20Plus	5' <i>0</i> "	1			
FJ10	1	14" PWI 205 or LPI 20Plus	3' <i>0</i> "	1			
FJ11	1	14" PWI 205 or LPI 20Plus	2'0"	1			
BM1	4	1-3/4x 14 2.0E 2900Fb PMT LVL	20'0"	4			
BM2	2	1-3/4x 14 2.0E 2900Fb PMT LVL	16' <i>0</i> "	2			
ВМЗ	4	1-3/4x 14 2.0E 2900Fb PMT LVL	8'O"	2			
BM4	2	1-3/4x 16 2.0E 2900Fb PMT LVL	22' <i>0</i> "	2			
BM5	2	1-3/4x 24 2.0E 2900Fb PMT LVL	22' <i>0</i> "	2			
BM6	2	1-3/4x 24 2.0E 2900Fb PMT LVL	16' <i>0</i> "	2			
BB04	2	1 $1/2" \times 7 1/4"$ Generic Material	10'0"	2			
RB1	14	1" x 14" BC RIM BOARD OSB	12'0"	1			
Bk1	1	14" PWI 205 or LPI 20Plus	17'0"	1			

Connector Summary				
PlotID	Qty	Manuf	Product	
H1	3		ITS2.56/14	
H 1	3	Simpson	ITS2.56/14	
H2	1	Simpson	ITS2.56/14	
НЗ	1	Simpson	IUS2.56/14	
H4	4	Simpson	NS2.56/14	
H5	18	Simpson	IUS2.56/14	

erelining.

General Notes:

- See Boise Cascade Installation Guide for Installation/Framing details.
- All Measurements to be verified in the field.
- All I-Joist, LVL beams, and Rim Board must be field cut to length.
- -Contractor to verify and approve the provided material list on this layout.
- -The material provided is sold as a complete package, custom cut for this job; therefore, any cut lengths or pieces of cut lengths MAY NOT be returned for credit.
- -Any material discrepancies must be reported before installation. Contact Talbert Building Supply at 336-599-1135.
- -See original blueprints for additional structural notes.
- -Ceramic tiles floors should be supported per APA standards. Additional joists may be required.
- -Plumbing, HVAC, and Electrical trade to reference Boise Cascade Specifier or Installation Guide for hole cutting information.
- Boise Cascade/Talbert Building Supply is NOT the Engineer of Record. These plans are for the EoR to review and verify all bracing/load points are picked up properly. These plans are for gravity loads only and NOT lateral. Design and pricing hinges on EoR review/approval.
- Framer Note: Install all LVL with stamps/printing facing out for visibilty.
- This layout was designed based on the Construction Documents and instruction provided to Talbert Building Supply by the contractor/home owner.

Builder:

Drees Homes

Job Name:

Brenner Residence Address:

Sneed Lane

Raleigh, NC

Date: 7/25/25 By: WH





