


- INSTALLATION INSTRUCTIONS**
1. WALL CABINET IS SHIPPED AS TWO PIECES. ENSURE FACES ARE BUTTED UP AGAINST EACH OTHER TO APPEAR SEAMLESS. THIS WILL AVOID RETURNING TO SITE TO ADJUST FACES AT INSTALLER COST.
 2. OPEN PACKAGING CAREFULLY AND INSPECT FOR DAMAGE. VERIFY SIGN TEMPLATE IS IN BOX. IF DAMAGE IS FOUND, CLAIM MUST BE FILED WITHIN 15 DAYS WITH SHIPPING AGENT.
 3. 8 MOUNTING ANGLE BRACKETS ARE SUPPLIED BY EVERBRITE. BRACKETS WILL BE MOUNTED TO CREATE HOLDING THE SIGN IN PLACE. BRACKETS MUST BE MOUNTED TO WALL PER SECTION VIEW.
 4. DETERMINE SIGN PLACEMENT BY REFERING TO ELEVATION/OVERLAY DRAWINGS. ADHERE TEMPLATE TO THE SURFACE TO WHICH THE SIGN WILL BE INSTALLED.
 5. LAYOUT AND PER-DRILL ALL MOUNTING AND ELECTRICAL HOLES REQUIRED FOR MOUNTING THE SIGN ON THE WALL AS IT IS TO BE INSTALLED PER ELEVATION DRAWINGS.
 6. ATTACH STEEL ANGLE MOUNTING BRACKETS TO WALL WITH APPROPRIATE MOUNTING HARDWARE. SUPPLIED BY INSTALLER. ALL FASTENERS SHALL BE ZINC COATED TO PREVENT CORROSION UNLESS NOTED OTHERWISE.
 7. ALL WALL PENETRATIONS SHALL BE SEALED TO PREVENT WATER INFILTRATION. EVERBRITE RECOMMENDS FILLING HOLES WITH SILICONE PRIOR TO INSTALLING HARDWARE.
 8. IF THE MOUNTING STRUCTURE HAS A VARYING SURFACE (I.E. METAL PANEL), SHIMS MAY BE REQUIRED TO PROVIDE UNIFORM MOUNTING SURFACE.
 9. IF THE STRUCTURE CANNOT PROPERLY SUPPORT THE SIGN, THE G.C. SHALL INSTALL UNISTRUT, 2X ANGLE OR OTHER APPROPRIATE BLOCKING BEHIND THE SURFACE TO PROVIDE PROPER SUPPORT FOR THE SIGN.
 10. THREADED ROD FASTENERS MAY BE REQUIRED TO REACH SUBSTRUCTURE OR INSTALLED BLOCKING (THE INSTALLER IS RESPONSIBLE FOR DETERMINING THE PROPER LENGTH OF THREADED ROD).
 11. IF THE MOUNTING SURFACE IS BRICK, USE AT LEAST 3/8" DIA HILTI HLC SLEEVE ANCHOR WITH A MINIMUM OF 1 1/4" EMBEDMENT.
 12. THREAD ONE END OF THE FASTENER/THREADED ROD THROUGH THE BACK OF THE CABINET JUST FAR ENOUGH TO APPLY THE WASHER AND NUT BUT NOT FAR ENOUGH TO TOUCH THE LAMPS ON THE INSIDE OF THE CABINET.
 13. PUSH THE CABINET, WITH THE FASTENERS/THREADED RODS EXTENDING OUT THE BACK, THROUGH THE PRE-DRILLED MOUNTING HOLES AND SECURE WITH HARDWARE.
 14. EACH WALL ELECTRICAL SIGN REQUIRES A DEDICATED 20 AMP CIRCUIT.
 15. MAKE FINAL ELECTRICAL SIGN HOOK UP TO PRIMARY WIRING PER NATIONAL ELECTRICAL CODE AND IF NEEDED PROVIDE WEATHER PROOK BOX, SUPPLIED BY INSTALLER. EVERBRITE SUPPLYS A 4" ELECTRICAL WHIP.
 16. TEST THE SIGN TO ENSURE THE SIGN IS LIGHTED AND FUNCTIONING PROPERLY.
 17. PERFORM TOUCH UP AS REQUIRED. ALL EXPOSED FASTENER HEADS SHALL BE PAINTED TO MATCH EXTERIOR CABINET. COLOR IS SEMI GLOSS BLACK.



SIGN SPECS
OVERALL DIMENSIONS OF SIGN :
HEIGHT : 45"
DEPTH : 312"
WIDTH WITH FACE : 7' 11/16"

LAMPS:
(4) F96T12 CW/HO
(4) F94T12 CW/HO
(8) FTZT12 CW/HO
BALLAST: (4) EESB-832-16L
9.6 AMPS @ 120VAC
(1) 20 AMP CIRCUIT, 60 Hz, UL 48 & NEC COMPLIANT

SIGN IS TO BE WIRED WITH 12 GAUGE MTW WIRE.
SIGN MUST BE GROUNDED WITH 12 GAUGE GREEN WIRE.

GENERAL NOTES
INCLUDE COMPLETION PHOTOS OF MOUNTING/CONNECTION POINTS. WALL MOUNT AND WELDING CONNECTIONS IF APPLICABLE.
THIS SIGN IS INTENDED TO BE INSTALLED IN ACCORDANCE WITH THE REQUIREMENTS OF ARTICLE 600 OF THE NATIONAL ELECTRIC CODE AND/OR OTHER APPLICABLE LOCAL CODES. THIS INCLUDES PROPER GROUNDING AND BONDING OF THE SIGN.

WALL MOUNT DETAIL
SCALE 1:10

REVISIONS		DRAWN BY SAJ		DATE 3-19-14		SCALE AS SHOWN		DWG NO. IN04322B		SITE STANDARD DRAWING	
C	REVISED SIGN ELECTRICAL SPECS	SAJ	RHB	7-7-15							
B	REVISED INSTRUCTIONS	SAJ	RHB	9-18-14							
A	RELEASED FOR INSTALL	SAJ	RHB	4-4-14							
REV.	DESCRIPTION	DATE	DRN	CHK	CHK'D BY	DATE	PIF REF	302864		REV.	C
<p>THESE DRAWINGS ARE THE EXCLUSIVE PROPERTY OF EVERBRITE, LLC. USE OF OR DUPLICATION IN ANY MANNER WITHOUT EXPRESS WRITTEN PERMISSION OF EVERBRITE, INC. IS PROHIBITED.</p> <p>Everbrite 4949 SO. 110TH ST. P.O. BOX 20020 GREENFIELD, WI 53220 414-529-3500</p>											